

SECTION **IDX**  
ALPHABETICAL INDEX

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

IDX

# ALPHABETICAL INDEX

Numerics	
4LO indicator lamp .....	<a href="#">TF-16</a>
4LO switch .....	<a href="#">TF-56</a> , <a href="#">TF-59</a>
4WD - Wiring diagram .....	<a href="#">TF-25</a>
4WD shift indicator lamp .....	<a href="#">TF-16</a>
4WD shift switch .....	<a href="#">TF-16</a> , <a href="#">TF-59</a> , <a href="#">TF-62</a>
4WD system description .....	<a href="#">TF-15</a>
4WD system diagram .....	<a href="#">TF-18</a>
4WD warning lamp .....	<a href="#">TF-17</a>
<b>A</b>	
A/C air flow .....	<a href="#">ATC-30</a> , <a href="#">MTC-30</a>
A/C compressor clutch removal and installation .....	<a href="#">ATC-143</a> , <a href="#">MTC-123</a>
A/C compressor mounting .....	<a href="#">ATC-142</a> , <a href="#">MTC-122</a>
A/C compressor precaution .....	<a href="#">ATC-12</a> , <a href="#">MTC-12</a>
A/C compressor special service tool .....	<a href="#">ATC-16</a> , <a href="#">MTC-16</a>
A/C control operation (auto A/C) .....	<a href="#">ATC-28</a> , <a href="#">MTC-28</a>
A/C diagnostic work flow (auto A/C) .....	<a href="#">ATC-103</a> , <a href="#">MTC-95</a>
A/C evaporator .....	<a href="#">ATC-149</a> , <a href="#">MTC-129</a>
A/C HFC134a (R134a) system precaution .....	<a href="#">ATC-4</a> , <a href="#">MTC-4</a>
A/C HFC134a (R134a) system service procedure .....	<a href="#">ATC-138</a> , <a href="#">MTC-118</a>
A/C HFC134a (R134a) system service tools ..	<a href="#">ATC-16</a> , <a href="#">MTC-16</a>
A/C HFC134a system service equipment precaution ...	<a href="#">ATC-12</a> , <a href="#">MTC-12</a>
A/C lubricant (R134a) .....	<a href="#">ATC-24</a> , <a href="#">MTC-24</a>
A/C lubrication oil .....	<a href="#">ATC-24</a> , <a href="#">MTC-24</a>
A/C operational check .....	<a href="#">ATC-57</a> , <a href="#">MTC-53</a>
A/C self-diagnoses (auto A/C) .....	<a href="#">ATC-55</a> , <a href="#">ATC-103</a> , <a href="#">MTC-51</a> , <a href="#">MTC-95</a>
A/C service data specification .....	<a href="#">ATC-154</a> , <a href="#">MTC-135</a>
A/C trouble diagnoses (auto A/C) .....	<a href="#">ATC-33</a> , <a href="#">MTC-33</a>
A/C, A - Wiring diagram .....	<a href="#">ATC-39</a> , <a href="#">MTC-39</a>
A/T fluid checking .....	<a href="#">AT-12</a> , <a href="#">AT-43</a> , <a href="#">MA-29</a>
A/T fluid replacement .....	<a href="#">AT-11</a> , <a href="#">MA-31</a>
A/T fluid temperature sensor .....	<a href="#">AT-118</a>
A/T IND - Wiring diagram .....	<a href="#">DI-49</a>
A/T indicator .....	<a href="#">DI-48</a>
A/T self-diagnoses .....	<a href="#">AT-89</a>
A/T shift lock system .....	<a href="#">AT-212</a>
A/T trouble diagnoses .....	<a href="#">AT-34</a>
A/T Wiring diagram AT - CAN .....	<a href="#">AT-92</a>
A/T Wiring diagram AT - FTS .....	<a href="#">AT-119</a>
A/T Wiring diagram AT - MAIN .....	<a href="#">AT-164</a>
A/T Wiring diagram AT - NONDTC .....	<a href="#">AT-174</a>
A/T Wiring diagram AT - PNP/SW .....	<a href="#">AT-100</a>
A/T Wiring diagram AT - STSIG .....	<a href="#">AT-95</a>
A/T Wiring diagram AT - VSS A/T .....	<a href="#">AT-105</a>
ABS - Wiring diagram .....	<a href="#">BRC-13</a>
Accelerator control system .....	<a href="#">ACC-2</a>
Accelerator pedal position (APP) sensor .....	<a href="#">EC-108</a> , <a href="#">EC-142</a> , <a href="#">EC-275</a>
Aiming adjustment .....	<a href="#">LT-28</a> , <a href="#">LT-85</a>
Air bag .....	<a href="#">SRS-3</a>
Air bag disposal .....	<a href="#">SRS-49</a>
Air bleeding (hydraulic clutch) .....	<a href="#">CL-8</a>
Air cleaner and air duct .....	<a href="#">EM-15</a>
Air cleaner filter .....	<a href="#">EM-17</a>
Air cleaner filter replacement .....	<a href="#">MA-25</a>
Air conditioner cut control .....	<a href="#">EC-20</a>
Air flow meter - See Mass air flow sensor .....	<a href="#">EC-92</a>
Air mix. door motor .....	<a href="#">ATC-68</a>
Alternator .....	<a href="#">SC-14</a>
Ambient sensor .....	<a href="#">ATC-105</a> , <a href="#">ATC-117</a>
Angular tightening application .....	<a href="#">EM-4</a>
APP2PW - Wiring diagram .....	<a href="#">EC-229</a>
APPS - Wiring diagram .....	<a href="#">EC-110</a>
APPS2 - Wiring diagram .....	<a href="#">EC-144</a>
APPS3 - Wiring diagram .....	<a href="#">EC-277</a>
ASC/BS - Wiring diagram .....	<a href="#">EC-192</a>
ASC/SW - Wiring diagram .....	<a href="#">EC-208</a>
ASCBOF - Wiring diagram .....	<a href="#">EC-331</a>
ASCD .....	<a href="#">EC-355</a>
ASCD (automatic speed control device) .....	<a href="#">ACS-2</a>
ASCD brake switch .....	<a href="#">EC-189</a> , <a href="#">EC-330</a>
ASCD clutch switch .....	<a href="#">EC-189</a> , <a href="#">EC-330</a>
ASCD indicator lamp .....	<a href="#">EC-351</a>
ASCD steering switch .....	<a href="#">EC-206</a>
ASCIND - Wiring diagram .....	<a href="#">EC-352</a>
ATP switch .....	<a href="#">TF-82</a> , <a href="#">TF-85</a>
Auto air conditioner - Wiring diagram .....	<a href="#">ATC-39</a> , <a href="#">MTC-39</a>
Auto anti-dazzling inside mirror .....	<a href="#">GW-45</a>
Autolamp .....	<a href="#">LT-49</a>
Automatic amplifier .....	<a href="#">ATC-60</a> , <a href="#">MTC-55</a>
Automatic transmission number .....	<a href="#">GI-58</a> , <a href="#">GI-59</a>
<b>B</b>	
Back door trim .....	<a href="#">EI-30</a>
BACK/L - Wiring diagram .....	<a href="#">LT-123</a>
Back-up lamp .....	<a href="#">LT-123</a>
Back-up lamp switch (M/T) .....	<a href="#">MT-12</a> , <a href="#">MT-19</a>
Ball joint (front) .....	<a href="#">FSU-15</a>
Barometric pressure (BARO) sensor .....	<a href="#">EC-293</a>
Basic inspection .....	<a href="#">EC-38</a>
Battery .....	<a href="#">SC-5</a>
Baulk ring (M/T) .....	<a href="#">MT-21</a>
BCM (Body control module) .....	<a href="#">BCS-3</a>
Blower motor ...	<a href="#">ATC-80</a> , <a href="#">ATC-121</a> , <a href="#">MTC-71</a> , <a href="#">MTC-100</a>
Body mounting .....	<a href="#">BL-189</a> , <a href="#">BL-190</a>
BOOST - Wiring diagram .....	<a href="#">EC-155</a>
Brake booster .....	<a href="#">BR-19</a>
Brake fluid level .....	<a href="#">MA-35</a>
Brake inspection .....	<a href="#">MA-35</a>
Brake lines and cables inspection .....	<a href="#">MA-35</a>
Brake master cylinder .....	<a href="#">BR-17</a>
Brake pedal .....	<a href="#">BR-6</a>
Brake switch .....	<a href="#">EC-330</a>
Bulb specifications .....	<a href="#">LT-173</a>
Bumper, front .....	<a href="#">EI-15</a>
Bumper, rear .....	<a href="#">EI-17</a>

# ALPHABETICAL INDEX

## C

Camshaft ..... [EM-59](#)  
Camshaft inspection ..... [EM-60](#)  
Camshaft position sensor (CMPS) ..... [EC-82](#), [EC-171](#),  
[EC-177](#)  
CAN ..... [DI-65](#)  
CAN - Wiring diagram ..... [EC-80](#), [LAN-26](#), [LAN-44](#),  
[LAN-56](#), [LAN-68](#), [LAN-82](#), [LAN-96](#), [LAN-112](#), [LAN-125](#),  
[LAN-139](#), [LAN-152](#), [LAN-166](#), [LAN-181](#), [LAN-198](#),  
[LAN-213](#), [LAN-230](#), [LAN-248](#), [LAN-267](#), [LAN-279](#)  
CAN (Controller Area Network) .. [BL-25](#), [BL-59](#), [RF-13](#)  
CAN communication ..... [EC-22](#), [EC-79](#), [AT-91](#), [TF-19](#),  
[TF-82](#), [RFD-43](#), [RFD-69](#), [BRC-28](#), [BL-25](#), [BL-59](#), [RF-13](#),  
[LT-88](#)  
CHARGE - Wiring diagram ..... [SC-15](#)  
Charging system ..... [SC-14](#)  
Chassis and body maintenance ..... [MA-28](#)  
CHIME - Wiring diagram ..... [DI-53](#)  
CIGAR - Wiring diagram ..... [WW-55](#)  
Cigarette lighter ..... [WW-55](#)  
Circuit breaker ..... [PG-74](#)  
CKPS - Wiring diagram ..... [EC-161](#), [EC-167](#)  
Clutch cover ..... [CL-17](#)  
Clutch disc ..... [CL-17](#)  
Clutch master cylinder ..... [CL-9](#)  
Clutch operating cylinder ..... [CL-11](#)  
Clutch pedal ..... [CL-6](#)  
CMPS - Wiring diagram ..... [EC-173](#), [EC-179](#)  
Coil spring (front) ..... [FSU-10](#)  
Collision diagnosis ..... [SRS-56](#)  
Combination lamp, front, removal and installation .....  
[LT-30](#)  
Combination lamp, rear, removal and installation .....  
[LT-144](#)  
Combination meter ..... [DI-4](#)  
Combination switch ..... [LT-114](#)  
COMBSW - Wiring diagram ..... [LT-114](#)  
COMPAS - Wiring diagram ..... [DI-68](#)  
Compass ..... [DI-66](#)  
Component Location (auto A/C) ..... [ATC-36](#), [MTC-36](#)  
Compression pressure ..... [EM-92](#)  
Compressor clutch removal and installation . [ATC-143](#),  
[MTC-123](#)  
Compressor mounting ..... [ATC-142](#), [MTC-122](#)  
Compressor special service tool ..... [ATC-16](#), [MTC-16](#)  
Condenser ..... [ATC-147](#), [MTC-127](#)  
Connecting rod ..... [EM-127](#)  
Connecting rod bearing clearance ..... [EM-131](#)  
Connecting rod bushing clearance ..... [EM-127](#)  
Console box - See Instrument panel ..... [IP-10](#)  
CONSULT for all-mode 4WD ..... [TF-44](#)  
CONSULT-II for engine ..... [EC-59](#)  
Control units (terminal arrangement) ..... [PG-78](#)  
Control valve (A/T) ..... [AT-33](#)  
Controller Area Network (CAN) .. [BL-25](#), [BL-59](#), [RF-13](#)  
Converter housing installation ..... [AT-250](#)  
COOL/F - Wiring diagram ..... [EC-135](#)  
Cooling circuit (engine) ..... [CO-6](#)

Cooling fan ..... [CO-19](#)  
Cooling fan motor ..... [EC-141](#)  
Cooling unit (A/C evaporator) ..... [ATC-124](#), [ATC-149](#),  
[MTC-103](#), [MTC-129](#)  
Counter gear (M/T) ..... [MT-21](#)  
Coupling sleeve (M/T) ..... [MT-21](#)  
Crankcase ventilation system ..... [EC-21](#)  
Crankshaft position sensor (TDC) ..... [EC-82](#), [EC-159](#),  
[EC-165](#)  
Cylinder block ..... [EM-110](#)  
Cylinder block boring ..... [EM-129](#)  
Cylinder head ..... [EM-92](#)  
Cylinder head bolt tightening ..... [EM-96](#)  
Cylinder head gasket selection ..... [EM-96](#)

## D

Data link connector for Consult ..... [EC-59](#)  
Daytime light system ..... [LT-31](#)  
Daytime running light - See Daytime light system [LT-31](#)  
Diagnosis sensor unit ..... [SRS-48](#)  
Diagnostic trouble code (DTC) ..... [EC-27](#)  
Diagnostic trouble code (DTC) for OBD system .. [EC-6](#)  
Diagnostic trouble code (DTC) inspection priority chart  
[EC-37](#)  
Differential gear oil replacement ..... [MA-33](#), [MA-34](#)  
DIFLOC - Wiring diagram ..... [RFD-46](#)  
Dimensions ..... [GI-60](#)  
Direct clutch solenoid valve ..... [AT-142](#), [AT-144](#)  
Display and amp. assembly ..... [ATC-60](#), [MTC-55](#)  
Dome light - See Interior lamp ..... [LT-145](#)  
Door glass ..... [GW-35](#), [GW-38](#)  
Door lock ..... [BL-126](#)  
Door mirror lamp ..... [LT-145](#)  
Door trim ..... [EI-30](#)  
Door, front ..... [BL-118](#), [BL-120](#), [GW-35](#)  
Door, rear ..... [BL-118](#), [GW-38](#)  
Drive belt ..... [EM-12](#)  
Drive chain (Transfer) ..... [TF-114](#), [TF-120](#)  
Driver air bag ..... [SRS-36](#)  
DTRL - Wiring diagram ..... [LT-35](#)  
Duct and grilles ..... [ATC-134](#), [MTC-113](#)

## E

ECM input/output signal ..... [EC-52](#)  
ECM power supply ..... [EC-71](#)  
ECM relay ..... [EC-232](#)  
ECTS - Wiring diagram ..... [EC-105](#)  
EGR function ..... [EC-302](#)  
EGR volume control valve ..... [EC-302](#)  
EGRC/V - Wiring diagram ..... [EC-304](#)  
Electric sunroof ..... [RF-10](#)  
Electrical units location ..... [PG-71](#)  
Electronic fuel injection pump ..... [EM-49](#)  
Engine control circuit diagram ..... [EC-50](#)  
Engine control component parts location ..... [EC-46](#)  
Engine control module (ECM) ..... [EC-213](#), [EC-215](#),  
[EC-269](#)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
IDX

# ALPHABETICAL INDEX

Engine control system diagram and chart .....	<a href="#">EC-15</a>	Fuel leak .....	<a href="#">EC-88</a>
Engine coolant .....	<a href="#">CO-7</a>	Fuel line inspection .....	<a href="#">FL-3</a>
Engine coolant temperature sensor (ECTS) ...	<a href="#">EC-103</a>	Fuel pump <a href="#">EC-86</a> , <a href="#">EC-217</a> , <a href="#">EC-245</a> , <a href="#">EC-251</a> , <a href="#">EC-258</a> ,	<a href="#">EC-263</a>
Engine oil .....	<a href="#">LU-5</a>	Fuel pump(Learning Value Clearing) .....	<a href="#">EC-24</a>
Engine oil filter replacement .....	<a href="#">MA-26</a>	Fuel rail pressure sensor .....	<a href="#">EC-118</a>
Engine oil precautions .....	<a href="#">GI-7</a>	Fuel system .....	<a href="#">FL-3</a>
Engine removal .....	<a href="#">EM-106</a>	Fuel tank .....	<a href="#">FL-9</a>
Engine room cover .....	<a href="#">EM-20</a>	Fuel temperature sensor .....	<a href="#">EC-113</a>
Engine serial number .....	<a href="#">GI-58</a>	Fuse .....	<a href="#">PG-74</a> , <a href="#">PG-84</a>
Evaporator .....	<a href="#">ATC-149</a> , <a href="#">MTC-129</a>	Fuse and fusible link box .....	<a href="#">PG-84</a>
Exhaust manifold .....	<a href="#">EM-34</a>	Fusible link .....	<a href="#">PG-74</a> , <a href="#">PG-84</a>
Exhaust system .....	<a href="#">EX-2</a>		
Exhaust system inspection .....	<a href="#">EX-2</a>		
Expansion valve .....	<a href="#">ATC-150</a> , <a href="#">MTC-130</a>		

## F

F/FOG - Wiring diagram .....	<a href="#">LT-74</a>
F/PUMP - Wiring diagram ..	<a href="#">EC-248</a> , <a href="#">EC-254</a> , <a href="#">EC-260</a> ,
<a href="#">EC-266</a>	
Final drive pre-inspection .....	<a href="#">FFD-18</a>
Final drive removal and installation ..	<a href="#">RFD-14</a> , <a href="#">RFD-81</a>
Flow charts .....	<a href="#">GI-24</a>
Fluid temperature sensor (A/T) .....	<a href="#">AT-118</a>
Fluids .....	<a href="#">MA-14</a>
Fluorescent leak detector .....	<a href="#">ATC-150</a> , <a href="#">MTC-131</a>
Flywheel (clutch) .....	<a href="#">CL-17</a>
Flywheel runout .....	<a href="#">EM-134</a>
Fog lamp, front .....	<a href="#">LT-71</a>
Foot lamp .....	<a href="#">LT-145</a>
Fork rod (M/T) .....	<a href="#">MT-23</a>
Freeze frame data .....	<a href="#">EC-28</a>
Front brake solenoid valve .....	<a href="#">AT-137</a> , <a href="#">AT-139</a>
Front bumper .....	<a href="#">EI-15</a>
Front case (Transfer) .....	<a href="#">TF-114</a> , <a href="#">TF-120</a>
Front combination lamp removal and installation	<a href="#">LT-30</a>
Front door .....	<a href="#">BL-118</a> , <a href="#">BL-120</a> , <a href="#">BL-126</a> , <a href="#">GW-35</a>
Front Door Trim .....	<a href="#">EI-30</a>
Front drive shaft (Transfer) ...	<a href="#">TF-114</a> , <a href="#">TF-120</a> , <a href="#">TF-133</a>
Front final drive removal and installation (4WD) .....	
<a href="#">FFD-15</a>	
Front fog lamp .....	<a href="#">LT-71</a>
Front passenger air bag .....	<a href="#">SRS-40</a>
Front seat .....	<a href="#">SE-20</a>
Front seat belt .....	<a href="#">SB-3</a> , <a href="#">SB-5</a>
Front seat belt pre-tensioner .....	<a href="#">SRS-3</a> , <a href="#">SRS-47</a>
Front side air bag .....	<a href="#">SRS-43</a>
Front washer .....	<a href="#">WW-4</a>
Front wiper .....	<a href="#">WW-4</a>
FRPS - Wiring diagram .....	<a href="#">EC-120</a>
FTS - Wiring diagram .....	<a href="#">EC-115</a>
Fuel cut control (at no load high engine speed) .	<a href="#">EC-20</a>
Fuel filler lid .....	<a href="#">BL-136</a>
Fuel filter .....	<a href="#">EC-23</a>
Fuel filter replacement .....	<a href="#">FL-4</a>
Fuel gauge .....	<a href="#">DI-4</a>
Fuel injection control system .....	<a href="#">EC-18</a>
Fuel injector .....	<a href="#">EC-25</a> , <a href="#">EC-123</a> , <a href="#">EC-125</a> , <a href="#">EC-237</a>
Fuel injector and fuel tube .....	<a href="#">EM-44</a>

## G

Garage jack and safety stand .....	<a href="#">GI-52</a>
Gauges .....	<a href="#">DI-4</a>
Gear components (M/T) .....	<a href="#">MT-21</a>
Generator .....	<a href="#">SC-14</a>
Generator - See Alternator .....	<a href="#">SC-14</a>
Glass .....	<a href="#">GW-11</a> , <a href="#">GW-35</a> , <a href="#">GW-38</a> , <a href="#">GW-43</a>
Glove box lamp .....	<a href="#">LT-162</a>
GLOW - Wiring diagram .....	<a href="#">EC-296</a>
Glow plug .....	<a href="#">EM-41</a> , <a href="#">EC-295</a>
Glow relay .....	<a href="#">EC-295</a>
Grease .....	<a href="#">MA-14</a>
Ground distribution .....	<a href="#">PG-27</a>

## H

H/AIM - Wiring diagram .....	<a href="#">LT-66</a>
Harness connector .....	<a href="#">PG-75</a>
Harness layout .....	<a href="#">PG-38</a>
Hazard warning lamp .....	<a href="#">LT-97</a>
Headlamp aiming control .....	<a href="#">LT-66</a>
Headlamp leveler - See Headlamp aiming control .....	
<a href="#">LT-66</a>	
Headlamp removal and installation .....	<a href="#">LT-30</a>
Heat up switch .....	<a href="#">EC-319</a>
Heated seat .....	<a href="#">SE-12</a>
Heater and cooling unit (Heater core) .....	<a href="#">ATC-124</a> ,
<a href="#">ATC-127</a> , <a href="#">MTC-103</a> , <a href="#">MTC-106</a>	
Heater unit (heater core) .....	<a href="#">ATC-124</a> , <a href="#">ATC-127</a> ,
<a href="#">MTC-103</a> , <a href="#">MTC-106</a>	
HEATUP - Wiring diagram .....	<a href="#">EC-320</a>
Height (Dimensions) .....	<a href="#">GI-60</a>
HFC134a (R134a) system precaution .	<a href="#">ATC-4</a> , <a href="#">MTC-4</a>
HFC134a (R134a) system service procedure	<a href="#">ATC-138</a> ,
<a href="#">MTC-118</a>	
HFC134a (R134a) system service tools .....	<a href="#">ATC-16</a> ,
<a href="#">MTC-16</a>	
HFC134a system service equipment precaution .....	
<a href="#">ATC-12</a> , <a href="#">MTC-12</a>	
High and low reverse clutch solenoid valve ....	<a href="#">AT-147</a> ,
<a href="#">AT-149</a>	
HLC - Wiring diagram .....	<a href="#">WW-41</a>
Horn .....	<a href="#">WW-59</a>
HORN - Wiring diagram .....	<a href="#">WW-59</a>
How to erase DTC .....	<a href="#">EC-27</a>

# ALPHABETICAL INDEX

HSEAT - Wiring diagram ..... [SE-14](#), [SE-17](#)

## I

IATS - Wiring diagram ..... [EC-100](#)  
Identification plate ..... [GI-57](#)  
Idle speed ..... [EC-38](#)  
Ignition key hole illumination ..... [LT-145](#)  
ILL - Wiring diagram ..... [LT-166](#)  
Illumination ..... [LT-162](#)  
In vehicle sensor ..... [ATC-108](#), [ATC-118](#)  
INJE/PW - Wiring diagram ..... [EC-284](#)  
INJECT - Wiring diagram ..... [EC-128](#), [EC-240](#), [EC-289](#)  
Injection nozzle ..... [EM-44](#), [EC-123](#), [EC-125](#), [EC-237](#)  
Injector adjustment value ..... [EC-271](#), [EC-273](#)  
Injector adjustment value registration ..... [EC-25](#)  
Input clutch solenoid valve ..... [AT-132](#), [AT-134](#)  
Instrument panel ..... [IP-10](#)  
INT/V - Wiring diagram ..... [EC-315](#)  
Intake air control valve control solenoid valve . [EC-314](#)  
Intake air temperature sensor ..... [EC-98](#)  
Intake door control linkage adjustment ..... [ATC-79](#)  
Intake door motor ..... [ATC-77](#), [ATC-129](#), [MTC-109](#)  
Intake manifold ..... [EM-20](#)  
Intake sensor .. [ATC-114](#), [ATC-120](#), [MTC-95](#), [MTC-99](#)  
Interior ..... [EI-33](#)  
Interior lamp ..... [LT-145](#)  
Interior lamp on-off control ..... [LT-145](#)  
IPDM (Intelligent power distribution module engine room) ..... [PG-14](#)  
ISO 15031-2 Terminology ..... [GI-61](#)

## J

Jacking points ..... [GI-52](#)

## K

Key illumination ..... [LT-145](#)  
KEYLES - Wiring diagram ..... [BL-93](#)

## L

Leaf spring (rear) ..... [RSU-7](#)  
Length (Dimensions) ..... [GI-60](#)  
License lamp ..... [LT-125](#)  
Lifting points ..... [GI-52](#)  
Line pressure solenoid valve ..... [AT-114](#)  
Line pressure test (A/T) ..... [AT-44](#)  
Liquid gasket application ..... [EM-5](#), [LU-2](#), [CO-2](#)  
Location of electrical units ..... [PG-71](#)  
Low coast brake solenoid valve ..... [AT-152](#), [AT-154](#)  
Lubricant (R134a) A/C ..... [ATC-24](#), [MTC-24](#)  
Lubricants ..... [MA-14](#)  
Lubrication circuit (engine) ..... [LU-4](#)  
Lubrication oil A/C ..... [ATC-24](#), [MTC-24](#)  
Lubrication-locks, hinges and hood latches ..... [MA-39](#)

## M

MAFS - Wiring diagram ..... [EC-94](#)  
Magnet clutch . [ATC-87](#), [ATC-143](#), [MTC-79](#), [MTC-123](#)  
MAIN - Wiring diagram ..... [EC-72](#)  
Main drive gear (M/T) ..... [MT-21](#)  
Mainshaft (M/T) ..... [MT-21](#)  
Major overhaul (Final drive) [FFD-17](#), [RFD-15](#), [RFD-82](#)  
Major overhaul (Transfer) ..... [TF-112](#)  
Malfunction indicator (MI) ..... [EC-28](#)  
Map lamp ..... [LT-145](#)  
Mass air flow sensor (MAFS) ..... [EC-92](#)  
Master cylinder (brake) ..... [BR-17](#)  
Master cylinder (clutch) ..... [CL-9](#)  
Meter ..... [DI-4](#)  
METER - Wiring diagram ..... [DI-10](#)  
MI & data link connectors circuit ..... [EC-354](#)  
MIL/DL - Wiring diagram ..... [EC-354](#)  
Mode door control linkage adjustment ..... [ATC-65](#),  
[MTC-59](#)  
Mode door motor ..... [ATC-63](#), [ATC-130](#), [MTC-58](#),  
[MTC-110](#)  
Model variation ..... [GI-56](#)  
Multiport fuel injection precautions ..... [GI-6](#)

## N

NATS - Wiring diagram ..... [BL-173](#)  
NATS (Nissan anti-theft system) precautions ..... [GI-3](#)  
NVH troubleshooting (AX) ..... [FAX-4](#)  
NVH troubleshooting (BR) ..... [BR-5](#)  
NVH troubleshooting (EM) ..... [EM-10](#)  
NVH troubleshooting (Final drive) ..... [FFD-6](#), [RFD-7](#),  
[RFD-39](#)  
NVH troubleshooting (M/T) ..... [MT-6](#)  
NVH troubleshooting (Propeller shaft) ..... [PR-2](#)  
NVH troubleshooting (ST) ..... [PS-5](#)  
NVH troubleshooting (Transfer) ..... [TF-11](#)  
NVH troubleshooting (WT)NVH troubleshooting (WT) .  
[WT-2](#)

## O

Oil cooler (engine) ..... [LU-11](#)  
Oil filter ..... [LU-8](#)  
Oil pan (engine) ..... [EM-36](#)  
Oil pressure (engine) ..... [LU-5](#)  
Oil pump (A/T) ..... [AT-281](#)  
Oil pump (engine) ..... [LU-14](#)  
Oil seal replacement (engine) ..... [EM-70](#)  
Oil seal replacement (front of final drive) ..... [FFD-9](#)  
Oil seal replacement (side of final drive) ..... [FFD-13](#)  
On board diagnostic system ..... [EC-27](#)  
Operating cylinder (clutch) ..... [CL-11](#)  
Overheat ..... [EC-132](#)  
Oversize piston ..... [EM-129](#)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

# ALPHABETICAL INDEX

## P

P/SCKT - Wiring diagram .....	<a href="#">WW-57</a>
Park/Neutral position switch .....	<a href="#">EC-342</a>
Park/neutral position switch (A/T) .....	<a href="#">AT-99</a>
Park/neutral position switch (M/T) .....	<a href="#">MT-12</a> , <a href="#">MT-19</a>
Parking brake control .....	<a href="#">PB-2</a>
Personal lamp .....	<a href="#">LT-145</a>
Pilot bushing replacement .....	<a href="#">EM-111</a>
Piston pin inspection .....	<a href="#">EM-125</a>
Piston ring inspection .....	<a href="#">EM-126</a>
Piston to bore clearance .....	<a href="#">EM-129</a>
Planetary carrier (Transfer) .....	<a href="#">TF-129</a>
PNP/SW - Wiring diagram .....	<a href="#">EC-343</a>
POWER - Wiring diagram .....	<a href="#">PG-5</a>
Power seat .....	<a href="#">SE-10</a>
Power steering fluid level .....	<a href="#">MA-37</a>
Power steering gear .....	<a href="#">PS-14</a>
Power steering oil pump .....	<a href="#">PS-25</a>
Power steering system bleeding .....	<a href="#">PS-6</a>
Power supply routing .....	<a href="#">PG-4</a>
Power window .....	<a href="#">GW-15</a>
Precautions for Leak detection dye ....	<a href="#">ATC-14</a> , <a href="#">MTC-14</a>
Precautions (General) .....	<a href="#">GI-4</a>
Pre-delivery inspection .....	<a href="#">MA-5</a>
Pressure plate - See Clutch cover .....	<a href="#">CL-17</a>
Pressure switch 1 .....	<a href="#">AT-139</a> , <a href="#">AT-156</a>
Pressure switch 2 .....	<a href="#">AT-154</a>
Pressure switch 3 .....	<a href="#">AT-134</a> , <a href="#">AT-158</a>
Pressure switch 5 .....	<a href="#">AT-144</a> , <a href="#">AT-160</a>
Pressure switch 6 .....	<a href="#">AT-149</a> , <a href="#">AT-162</a>
Pressure test (A/T) .....	<a href="#">AT-44</a>
Priming pump .....	<a href="#">EC-23</a>
Propeller shaft .....	<a href="#">PR-3</a> , <a href="#">PR-7</a>
Propeller shaft inspection .....	<a href="#">MA-32</a>
Propeller shaft on vehicle service .....	<a href="#">PR-7</a>
Propeller shaft vibration .....	<a href="#">PR-3</a> , <a href="#">PR-7</a>

## Q

Quick-glow system .....	<a href="#">EC-295</a>
-------------------------	------------------------

## R

R/FOG - Wiring diagram .....	<a href="#">LT-89</a>
Radiator .....	<a href="#">CO-11</a> , <a href="#">CO-15</a>
Rear bumper .....	<a href="#">EI-17</a>
Rear case (Transfer) .....	<a href="#">TF-114</a> , <a href="#">TF-120</a>
Rear combination lamp removal and installation .....	<a href="#">LT-144</a>
Rear cover packing replacement diff. ....	<a href="#">FFD-14</a>
Rear door .....	<a href="#">GW-38</a>
Rear seat .....	<a href="#">SE-29</a>
Rear seat belt .....	<a href="#">SB-7</a> , <a href="#">SB-9</a>
Rear window .....	<a href="#">GW-43</a>
Rear window defogger .....	<a href="#">GW-47</a>
Refrigerant connection precaution .....	<a href="#">ATC-5</a> , <a href="#">MTC-5</a>
Refrigerant discharging evacuating charging .....	<a href="#">ATC-138</a> , <a href="#">MTC-118</a>

Refrigerant general precaution .....	<a href="#">ATC-5</a> , <a href="#">MTC-5</a>
Refrigerant lines .....	<a href="#">ATC-138</a> , <a href="#">ATC-146</a> , <a href="#">ATC-147</a> , <a href="#">MTC-118</a> , <a href="#">MTC-126</a> , <a href="#">MTC-127</a>
Refrigerant pressure sensor .....	<a href="#">EC-325</a> , <a href="#">ATC-92</a> , <a href="#">ATC-147</a> , <a href="#">MTC-85</a> , <a href="#">MTC-127</a>
Refrigeration cycle .....	<a href="#">ATC-20</a> , <a href="#">MTC-20</a>
Relay box .....	<a href="#">PG-85</a>
Removal and installation (A/T) .....	<a href="#">AT-247</a>
Removal and installation (Transfer) .....	<a href="#">TF-111</a>
Reverse idler shaft (M/T) .....	<a href="#">MT-21</a>
Reverse lamp switch (M/T) - See Back-up lamp switch (M/T) .....	<a href="#">MT-12</a> , <a href="#">MT-19</a>
Reverse main gear (M/T) .....	<a href="#">MT-21</a>
Revolution sensor (A/T) .....	<a href="#">AT-103</a> , <a href="#">AT-238</a>
Road wheel size .....	<a href="#">GI-60</a>
Rocker cover .....	<a href="#">EM-56</a>
Room lamp .....	<a href="#">LT-145</a>
Room lamp - See Interior lamp .....	<a href="#">LT-145</a>
ROOM/L - Wiring diagram .....	<a href="#">LT-149</a>
RP/SEN - Wiring diagram .....	<a href="#">EC-326</a>

## S

S/SIG - Wiring diagram .....	<a href="#">EC-348</a>
SCTC/V - Wiring diagram .....	<a href="#">EC-219</a>
SEAT - Wiring diagram .....	<a href="#">SE-10</a> , <a href="#">SE-11</a>
Seat belt inspection .....	<a href="#">SB-11</a> , <a href="#">MA-40</a>
Seat belt pre-tensioner .....	<a href="#">SRS-47</a>
Seat belt pre-tensioner disposal .....	<a href="#">SRS-49</a>
Seat belt, front .....	<a href="#">SB-3</a> , <a href="#">SB-5</a>
Seat belt, rear .....	<a href="#">SB-7</a> , <a href="#">SB-9</a>
Seat, front .....	<a href="#">SE-20</a>
Seat, rear .....	<a href="#">SE-29</a>
Self-diagnosis (Transfer) .....	<a href="#">TF-49</a>
SHIFT - Wiring diagram .....	<a href="#">AT-213</a>
Shift control (Transfer) .....	<a href="#">TF-135</a>
Shift control components (M/T) .....	<a href="#">MT-23</a>
Shift fork (M/T) .....	<a href="#">MT-23</a>
Shift lever .....	<a href="#">MT-13</a>
Shift lock system .....	<a href="#">AT-212</a>
Shock absorber (front) .....	<a href="#">FSU-11</a>
Shock absorber (rear) .....	<a href="#">RSU-6</a>
Side air bag .....	<a href="#">SRS-43</a>
Side air bag (satellite) sensor .....	<a href="#">SRS-46</a>
Side curtain air bag .....	<a href="#">SRS-44</a>
Side trim .....	<a href="#">EI-33</a>
SMJ (super multiple junction) .....	<a href="#">PG-81</a>
Spare tire size .....	<a href="#">GI-60</a>
Speedometer .....	<a href="#">DI-4</a>
Spiral cable .....	<a href="#">SRS-38</a>
SROOF - Wiring diagram .....	<a href="#">RF-14</a>
SRS - See Supplemental Restraint System ....	<a href="#">SRS-6</a>
SRS - Wiring diagram .....	<a href="#">SRS-13</a>
SRS Trouble diagnoses .....	<a href="#">SRS-9</a>
Stabilizer bar (front) .....	<a href="#">FSU-12</a>
Stall test (A/T) .....	<a href="#">AT-43</a>
Standardized relay .....	<a href="#">PG-79</a>
START - Wiring diagram .....	<a href="#">SC-28</a>
Start signal .....	<a href="#">EC-348</a>

# ALPHABETICAL INDEX

Starter .....	<a href="#">SC-27</a>
Starting system .....	<a href="#">SC-27</a>
Steering gear, linkage and transfer gear inspection .....	<a href="#">MA-36</a> , <a href="#">MA-37</a>
Steering linkage .....	<a href="#">PS-14</a>
Steering wheel and column .....	<a href="#">PS-8</a>
Step lamp .....	<a href="#">LT-145</a>
Stop lamp .....	<a href="#">LT-121</a>
Stop lamp switch .....	<a href="#">EC-330</a>
STOP/L - Wiring diagram .....	<a href="#">LT-121</a>
Striking rod (M/T) .....	<a href="#">MT-23</a>
Strut (front) .....	<a href="#">FSU-10</a>
Sun roof, electric .....	<a href="#">RF-10</a>
Sunload sensor .....	<a href="#">ATC-112</a>
Sunroof .....	<a href="#">RF-10</a> , <a href="#">RF-21</a>
Super lock .....	<a href="#">BL-55</a>
Supplemental Restraint System .....	<a href="#">SRS-6</a>
Symbols and abbreviations .....	<a href="#">GI-10</a> , <a href="#">GI-23</a>
Symptom matrix chart .....	<a href="#">EC-42</a>
Synchronizer (M/T) .....	<a href="#">MT-21</a>

## T

Tachometer .....	<a href="#">DI-4</a>
Tail lamp .....	<a href="#">LT-125</a>
TAIL/L - Wiring diagram .....	<a href="#">LT-127</a>
TC boost control solenoid valve .....	<a href="#">EC-309</a>
TC boost sensor .....	<a href="#">EC-153</a>
TCC/V - Wiring diagram .....	<a href="#">EC-311</a>
TCM circuit diagram .....	<a href="#">AT-42</a>
TCM inspection table .....	<a href="#">AT-76</a>
Thermostat .....	<a href="#">CO-24</a>
Three way catalyst precautions .....	<a href="#">GI-5</a>
Throttle body .....	<a href="#">EM-20</a>
Tie-rod .....	<a href="#">PS-14</a>
Timing chain .....	<a href="#">EM-73</a> , <a href="#">EM-79</a>
Timing gear .....	<a href="#">EM-79</a>
Tire rotation .....	<a href="#">MA-34</a>
Tire size .....	<a href="#">GI-60</a>
Torque converter installation .....	<a href="#">AT-250</a>
Torque convertor clutch solenoid valve .....	<a href="#">AT-110</a> , <a href="#">AT-112</a>
Tow truck towing .....	<a href="#">GI-53</a>
Towing point .....	<a href="#">GI-54</a>
Transfer control device .....	<a href="#">TF-74</a> , <a href="#">TF-78</a> , <a href="#">TF-105</a>
Transfer control unit inspection table .....	<a href="#">TF-38</a>
Transfer oil replacement .....	<a href="#">MA-32</a>
Transfer serial number .....	<a href="#">GI-58</a>
Transmission case (M/T) .....	<a href="#">MT-19</a>
Transmission serial number .....	<a href="#">GI-58</a> , <a href="#">GI-59</a>
Tread-FR&RR (Dimensions) .....	<a href="#">GI-60</a>
Trim .....	<a href="#">EI-33</a>
Trouble diagnoses .....	<a href="#">GI-11</a>
Turbine revolution sensor .....	<a href="#">AT-123</a>
Turbocharger .....	<a href="#">EM-28</a>
Turbocharger charge air cooler .....	<a href="#">EM-18</a>
Turbocharger precautions .....	<a href="#">GI-6</a>
TURN - Wiring diagram .....	<a href="#">LT-100</a>
Turn signal lamp .....	<a href="#">LT-97</a>
Two-pole lift .....	<a href="#">GI-52</a>

## V

Vacuum hose drawing (Engine control) .....	<a href="#">EC-16</a>
Vacuum pump .....	<a href="#">EM-42</a>
Valve clearance .....	<a href="#">EM-66</a>
Valve guide .....	<a href="#">EM-101</a>
Valve lifter .....	<a href="#">EM-62</a>
Valve seat .....	<a href="#">EM-103</a>
Valve spring .....	<a href="#">EM-104</a>
Vanity mirror lamp .....	<a href="#">LT-145</a>
Vehicle identification number .....	<a href="#">GI-57</a>
Vehicle recovery (freeing a stuck vehicle) .....	<a href="#">GI-54</a>
VEHSEC - Wiring diagram .....	<a href="#">BL-143</a>
Viscosity number (SAE) .....	<a href="#">MA-15</a>

## W

Wait detection switch .....	<a href="#">TF-63</a> , <a href="#">TF-66</a>
WARN - Wiring diagram .....	<a href="#">DI-30</a>
Warning chime .....	<a href="#">DI-51</a>
Warning lamps .....	<a href="#">DI-28</a>
Washer, front .....	<a href="#">WW-4</a>
Water pump .....	<a href="#">CO-21</a>
Water temperature gauge .....	<a href="#">DI-4</a>
Wheel alignment (front) .....	<a href="#">FSU-7</a>
Wheel balance .....	<a href="#">MA-34</a>
Wheel bearing (front) .....	<a href="#">FAX-5</a>
Wheel bearing (rear) .....	<a href="#">RAX-6</a>
Wheel sensors (ABS) .....	<a href="#">BRC-37</a>
Wheel size .....	<a href="#">GI-60</a>
Wheelbase (Dimensions) .....	<a href="#">GI-60</a>
Width (Dimensions) .....	<a href="#">GI-60</a>
WINDOW - Wiring diagram .....	<a href="#">GW-20</a>
Window, door .....	<a href="#">GW-35</a> , <a href="#">GW-38</a>
Window, rear .....	<a href="#">GW-43</a>
Windshield .....	<a href="#">GW-11</a>
WIPER - Wiring diagram .....	<a href="#">WW-12</a>
Wiper, front .....	<a href="#">WW-4</a>
Wiring Diagram (Cell code) list .....	<a href="#">PG-68</a>
Wiring diagrams .....	<a href="#">GI-15</a>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

IDX